
Software Release Notes

Secure Series display panels firmware v7.82.3.0

This document provides firmware update instructions and describes known and fixed issues in firmware version 7.82.3.0 for the Secure Series display panels.

Affected products

The following products are affected.

- SUHD551-L
- SUHD651-L

New features

The following new features and enhancements are included in this release.

- Initial firmware release

Upgrading the firmware from USB

Install the new firmware to upgrade the display panels.

1. Download the latest software from www.christiedigital.com and unzip the file.
2. Navigate to `core_update/secure_7.82.3.0_mb120.bin`.
3. Copy the `secure_7.82.3.0_mb120.bin` file to the root of a USB storage device.
4. On the USB storage device, rename the file to `upgrade_mb120.bin`.
5. Connect the USB storage device to the display panel.
6. If the Media Browser is displayed, to close it press **Exit** on the remote.
7. On the display panel remote, press **Menu > 1505**.
8. In the confirmation dialog, select **Yes**.

During the upgrade process the display panel restarts. After the display panel restarts, while the upgrade finishes nothing is displayed on the panel and a red LED blinks in the top right corner. The process may take a few minutes to complete.

Updating the VGA settings

Correct an issue where there was noise on VGA connections.

1. Download the latest software from www.christiedigital.com and unzip the file.
2. On the USB storage device, create a folder called **PQ**.
3. Copy the `G6F_Main.bin` and `G6F_Main_Text.bin` files to the PQ folder.
4. Connect the USB storage device to the display panel.

5. If the Media Browser is displayed, to close it press **Exit** on the remote.
6. On the display panel remote, press **Menu > 4725**.
7. In the confirmation dialog, select **Yes**.
During the upgrade process the display panel restarts. After the display panel restarts, while the upgrade finishes nothing is displayed on the panel and a red LED blinks in the top right corner. The process may take a few minutes to complete.

Updating the profile

Apply settings to the display panel.

1. Download the latest software from www.christiedigital.com and unzip the file.
2. On the USB storage device, at the root create a folder called **Profile**.
3. Copy the `MB120_swprofile.bin` file to the Profile folder.
4. Connect the USB storage device to the display panel USB-1 port.
5. If the Media Browser is displayed, to close it press **Exit** on the remote.
6. On the display panel remote, press **Menu > 4725**.
7. Select **USB operations** and on the remote press **OK**.
8. In the confirmation dialog, select **Yes**.
During the upgrade process the display panel restarts. After the display panel restarts, while the upgrade finishes nothing is displayed on the panel and a red LED blinks in the top right corner. The process may take a few minutes to complete.

Product documentation

For installation, setup, and user information, see the product documentation available on the Christie website. Read all instructions before using or servicing this product.

1. Access the documentation from the Christie website:
 - Go to this URL: <http://bit.ly/2rO6SF6>.
 - Scan the QR code using a QR code reader app on a smartphone or tablet.



2. On the product page, select the model and switch to the **Downloads** tab.

Related documentation

Additional information on the LCD panels is available in the following documents.

- *Secure Series LCD Panels Product Safety Guide (P/N: 020-001667-XX)*
- *Secure Series LCD Panels Installation and Setup Guide (P/N: 020-001660-XX)*
- *Installing the Touch Overlay (P/N: 020-102431-XX)*
- *Secure Series LCD Panels External Controls (P/N: 020-001668-XX)*

Technical support

Technical support for Christie products is available at:

- North and South America: +1-800-221-8025 or *Support.Americas@christiedigital.com*
- Europe, Middle East, and Africa: +44 (0) 1189 778111 or *Support.EMEA@christiedigital.com*
- Asia Pacific: +65 6877-8737 or *Support.APAC@christiedigital.com*